





KEY FEATURES

- Intuitive touch screen for easy programmability
- Corrects flow for changes in back pressure, temperature, and atmospheric pressure
- Constant flows from 20 to 500 ml/min
- Bluetooth® low-energy (BLE) communication
 - With PC and DataTrac® Pro Software
 - With iOS® and Android® tablets and phones using the free SKC SmartWave app
 - Non-BLE pump models available (visit www.skcinc.com)
- Large backlit screen

- > 20+ hours run time at 500 ml/min with powerful Li-Ion battery
 - Auto-dim feature conserves battery
 - Extended run times with AC adapter/charger
- Multi-tube Sampling
 - Sample with up to four tubes simultaneously; saves time and uses fewer pumps
 - Constant flow and pressure modes
- Screen lock prevents accidental tap errors
- SecureLock feature provides for passcodesecured sampling
- Designed to meet ISO 13137





Bluetooth communication with PC and DataTrac Pro Software or phones/tablets with SmartWave App for remote pump monitoring



USB charging with magnetic connector and sure-connect LED indicator



Exhaust port with optional quick-connect accessory for secure bag sampling



Easy calibration with Low Flow chek-mate Calibrator

PERFORMANCE PROFILE

Flow Range in Constant Flow

Mode

20 to 500 ml/min

Compensation Range in Constant 20 to 500 ml/min up to 20 inches water back pressure

Flow Mode

Pressure Range in Constant

Pressure Mode

1 to 20 inches water

Flow Control System

Corrects for changes in back pressure, temperature, and atmospheric pressure

Power

Removable rechargeable Lithium-ion (Li-Ion) battery, 3.7 V, 2.6 Ah, 9.6 Wh or USB charger

Run Time (Li-Ion)

20+ hrs at 500 ml/min up to 20 inches water back pressure*, extended run times available with charger

Accuracy

Constant flow control: ± 5% of set-point or ± 3 ml/min, whichever is higher

Atmospheric pressure: ± 0.3 in Hg

Temperature: ± 1 C Real-time clock: ± 1%

Constant pressure mode: Reading ± 0.5 inch water

Temperature Ranges

Operating: 32 to 113 F (0 to 45 C); Charging: 32 to 113 F (0 to 45 C); Storage: -4 to 113 (-20 to 45 C)

Humidity Range

≤ 95% RH, non-condensing

Altitude

Corrects flow for changes in temperature (32 to 113 F [0 to 45 C]) and ambient pressure up to 15,000 feet (4572 meters)

above and down to 2300 feet (701 meters) below sea level

Flow Fault

After 3 to 10 seconds of restricted flow, pump stops, elapsed time stops, status LEDs flash red, and pump displays fault icon. After 20 seconds in fault, auto-restart is attempted up to 5 times unless full airflow is restored. If full airflow is not restored

after 5 auto-restart attempts within 5 minutes, the pump ends the run and displays Sample Summary.

Display Type/Parameters

High-contrast backlit LCD/Time, date, battery status, flow rate, sample volume, temperature, atmospheric pressure, back

pressure, programmed run remaining time, and elapsed run time

User Interface

Eight-area capacitive touch screen with auto-dim and locking options

Dimensions

3.2 x 3.8 x 1.5 in (8.1 x 9.7 x 3.8 cm)

Weight

8.3 oz (235 gm)

Certifications/Markings

-Intrinsic safety (SKC Cat. No. 220-1000TC operated with SKC Battery Pack Cat. No. P76303) Class I, Groups A, B, C, D; Class II, Groups E, F, G; Class III, T4;

Class I, Zone 0, Group IIC T4; Exia -20°C ≤ T₂ ≤ 45°C

⟨Ex⟩ II 1G Exia IIC T4 Ga

IECEx UL 16.0113

DEMKO 16ATEX 1600; UL22UKEX2584; UKCA 0843†

-RoHS compliant

F62011

Communications with PC

Low-energy Bluetooth, requires DataTrac Pro for Pocket Pump TOUCH USB Bluetooth Adapter Cat. No. 877-94

Communications with iOS or **Android Phones and Tablets**

Low-energy Bluetooth, requires SmartWave App - available in the App Store and GooglePlay

Tubing Requires 1/4-in ID tubing

Tested using 37-mm, 0.8-µm MCE filter with new pump and battery. Pump performance may vary.



ORDERING

Available as Cat. No.

220-1000TC Pocket Pump TOUCH Pump only

 220-1000TC-S
 Starter Pump Kit

 220-1000TC-K
 Single Pump Kit

 220-1000TC-K3
 3-pack Pump Kit

 220-1000TC-K5
 5-pack Pump Kit

 220-1000TC-K5D
 5-pack Deluxe Pump Kit

"Pump only" requires charger that is included in kits. See more at www.skcinc.com.

All models listed above include Bluetooth (BLE). Non-BLE models are available.

Recommended Calibrator[†]

375-00205N chek-mate with NIST standard traceable calibration certificate 375-00205 chek-mate with UK standard traceable calibration certificate

[†]Available with ISO standard traceable certificate. Contact SKC for details.

Recommended Accessories

220-200 Quick-connect Bag Sampling Adapter

877-94 DataTrac Pro for Pocket Pump TOUCH USB Bluetooth Adapter (free software download)

For ordering details and additional accessories, visit www.skcinc.com

FREE **SKC SMARTWAVE** APP



Set up flow, operate sample runs, and monitor status for one or more in-range Pocket Pump TOUCH pumps using your iOS and Android phones and tablets.

Visit <u>www.skcinc.com/smartwave</u>





